

# **HURON™** Travel Mug with Leak-Proof SNAPSEAL® Lid

16 fl. oz | 473 mL

# CARE AND USE INSTRUCTIONS

#### IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY

### **ACAUTION**

- Careful. The beverage you are about to enjoy may be very hot. For best results always use caution
- Keep out of reach of children when filled with hot liquids. To properly use your SNAPSEAL™ mug:



Snap up to drink with mua in upright position.



Snap down to seal.

- Prior to drinking, make sure the lid is properly threaded to the body and screwed down completely
- If filling with boiling liquid, allow liquid to cool down WITH THE LID OFF for at least 3 minutes before attaching the lid.

  When attaching lid, make sure the drink seal is in the open position.

  DO NOT overfill. Fill liquids to just below the fill line in the body as shown.

  DO NOT microwave or freeze.

  DO NOT use cleaners containing bleach, chlorine, abrasives,

- and/or other harsh chemicals
- and/or other natsh chemicals.
  DO NOT continue to use product if damaged.
  DO NOT carry bottles containing liquid in bags to help prevent accidental opening.



Fill line

#### USAGE RECOMMENDATIONS

- Suitable for hot or cold beverages.
  The SNAPSEAL™ lid that came with your new purchase is designed to fit only your new mug. Not for use with other products.
  To attach the lid, apply slight downward pressure and rotate counter-clockwise
- until you hear a click and lid falls into place. Then rotate lid clockwise to tighten completely.

#### CLEANING INSTRUCTIONS

- Wash thoroughly before first use.
- Snap open the drink seal before rinsing or washing.
  RINSE LID IMMEDIATELY AFTER EACH USE with warm water.
- Lid and UNPAINTED stainless steel body are top-rack dishwasher safe. HAND-WASH ONLY any PAINTED stainless steel body. To wash by hand, soak the lid for 10 minutes in hot, soapy tap water. Hand-wash the body with warm water and a mild detergent. Rinse both
- the lid and body thoroughly before use.

  ALWAYS STORE MUG WITH LID REMOVED to allow parts to dry completely.

### ADDITIONAL CLEANING TIPS

For additional product cleaning tips, please visit www.GoContigo.com/cleaning.

©2023 Contigo Brands Product of: Contigo Brands Chicago, IL 60601 www.GoContigo.com We would love to hear from you. 1.888.262.0622



\*Limited lifetime guarantee only applicable in US & Canada. See GoContigo.com for details.



STREETERVILLE™ Mug with Splash-Proof Lid 12 fl. oz | 414 mL

# **CARE AND USE INSTRUCTIONS**

## IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY

#### **▲**CAUTION

- Careful. The beverage you are about to enjoy may be very hot. For best results, always use caution. Lid is not leak or spill proof
- Not for use with carbonated, pulpy or perishable beverages
- DO NOT microwave or freeze.
- DO NOT use cleaners containing bleach, chlorine, abrasives and/or other harsh chemicals.
- DO NOT continue to use if damaged.
- DO NOT carry bottles containing liquid in bags to helpprevent accidental opening. DO NOT overfill.
- Keep out of reach of children when filled with hot liquids
- If filling with boiling liquid, allow liquid to cool down WITH THE LID OFF for at least 3 minutes before attaching the lid.

#### **USAGE RECOMMENDATIONS**

- Mug & Splash-Proof Lid suitable for hot or cold beverages.
  Press lid down on body until secure.
  Use the mug's slider to open and close the drink spout

#### CLEANING INSTRUCTIONS

- Wash thoroughly before first use.
   RINSE IMMEDIATELY AFTER EACH USE with warm water.
- Lid and body are top-rack dishwasher safe or can be hand washed.

   When washing by hand, soak lid, and body for 10 minutes in hot, soapy water.

   Hand wash body and lid with warm water in a mild detergent.
- Rinse thoroughly.

©2023 Contigo Bran Product of: Contigo Brands Chicago, IL 60601 www.GoContigo.com We would love to hear from you. 1.888.262.0622



\*Limited lifetime gu only applicable in US & Canada. See GoContigo.com for details.