

### USE AND CARE INSTRUCTIONS

**⚠ WARNING:** Not for use with carbonated beverages.  
Do not freeze or microwave. Store with lid removed.

**⚠ CAUTION:**

- Not intended for children under 3 years of age.
- Product is NOT designed for hot liquids. Use only with cold liquids.  
DO NOT use with carbonated or pulpy beverages.
- Prior to drinking, make sure the lid is properly threaded to the body and screwed completely.
- DO NOT overfill. Fill liquid just below the threading on the bottle.
- DO NOT use cleaners containing bleach, chlorine, abrasives, and/or harsh chemicals.
- DO NOT continue to use if product is damaged.

### HOW TO USE

Unscrew lid,  
sip from wide mouth.

- Leak-proof lid.






### HOW TO CLEAN

1. Unscrew lid. Open lid.



- Top rack dishwasher safe.
- RINSE LID IMMEDIATELY AFTER EACH USE with warm water.
- If washing by hand, soak lid for 10 minutes in hot, soapy water. Hand wash body with warm water and a mild detergent.
- Rinse both lid and body thoroughly before use..



\*Limited Lifetime Guarantee only  
applicable in the US & Canada.  
Visit [GoContigo.com](http://GoContigo.com) for details.